




REINVENTADO CAUCHO
- LIBRE DE AMONIACO -



UN FUTURO MAS LIMPIO


Restaurando el Medio Ambiente con
Látex de Caucho Natural sin Amoniaco

Prof. Tim A. Osswald Eric Adler Julio César Rodríguez Prof. Allen J. Román






1 kg of natural rubber sequesters 3 kg of CO₂





Natural rubber latex tree tapping process

LIQUID LATEX COLLECTION




STABILIZATION-PRESERVATION



PRODUCT DEVELOPMENT




NATURAL RUBBER LIQUID LATEX





Natural rubber latex and pH



THE PROBLEM

THE PROBLEM


Ammonia is a common preservative and stabilizer



AMMONIATED RUBBER


ZnO and TMTD

- Hazardous to health of workers
- Environmentally damaging
- Effluents promote unwanted algae growth
- Contains carcinogenic nitrosamines





Natural rubber latex and pH



THE SOLUTION

THE BREAKTHROUGH


Environmentally friendly additives stabilize and preserve the liquid latex



AFLAtex
technologies

35% - 100% dry
natural rubber

- Superior strength
- Odorless and non-toxic
- No water treatment facilities required
- No negative health consequences to workers and users





AFLATEX STABILIZATION FORMULATIONS

BETA

Formulation (by volume):
98% Natural rubber field latex
2% Linear DBS (**CAS: 85536-14-7**)

DBS = Dodecylbenzene sulfonic acid


Important note

Some chemical suppliers may offer CAS: 27176-87-0 which is the most expensive option for DBS as it's the purest form of the chemical.

Mixing:

Beta requires intense mixing, such as a drill-powered mixer

Note: Stabilization should occur no longer than 3 1/2 hours after collection






Mixing of 2% dodecylbenzene sulfonic acid and field latex

BETA STABILIZATION PROCESS



VISCOSITY DURING STABILIZATION





AFLATEX STABILIZATION FORMULATIONS

ALFA

Formulation (by volume):
98.6% Natural rubber field latex
1.4% volume of chemical premixture

Chemical premixture formulation (by volume):
29% hydrofluoric acid (50% concentration)
(CAS:7664-39-3)
71% Ethoxylated alcohol (7 moles)
(CAS: 68551-12-2)

Mixing:

Alfa can be mixed by hand


Note: Stabilization should occur no longer than 3 ½ hours after collection



AFLATEX CENTRIFUGING PROCESS




Notes: Latex can be centrifuged anytime after stabilization



Notes:

1. No maturation time is required after centrifuging
2. Centrifuge must be cleaned every 2 hours when in use
3. Shelf life of 6 years and counting

EFFECT OF HF IN ALFA



NITROSAMINE TESTING



TABLE 1: NITROSAMINES TESTING

AFLatex Alfa Field Latex	
PARAMETER	RESULTS, ug/kg
N-Nitroso-di-n-propylamine	<10
N-Nitrosomethylethylamine	<10
N-Nitrosodi-n-butylamine	<10
N-Nitrosodimethylamine	<10
N-Nitrosodiethylamine	<10
N-Nitrosopyrrolidine	<10
N-Nitrosopiperidine	<10
N-Nitrosomorpholine	<10
N-Nitrosodiethylphenylamine	<10
N-Nitrosomethylphenylamine	<10
N-Nitrosodiisobutylamine	<10
N-Nitrosodibenzylamine	<10



TABLE 2: NITROSAMINES TESTING


AFLatex Alfa Concentrated Latex	
PARAMETER	RESULTS, ug/kg
N-Nitroso-di-n-propylamine	<10
N-Nitrosomethylethylamine	<10
N-Nitrosodi-n-butylamine	<10
N-Nitrosodimethylamine	<10
N-Nitrosodiethylamine	<10
N-Nitrosopyrrolidine	<10
N-Nitrosopiperidine	<10
N-Nitrosomorpholine	<10
N-Nitrosodiethylphenylamine	<10
N-Nitrosomethylphenylamine	<10
N-Nitrosodiisobutylamine	<10
N-Nitrosodibenzylamine	<10

ALL NITROSAMINES WERE UNDETECTED

EPA 8270-SIM Testing: Performed at ARDL

PARTICLE SIZE DISTRIBUTION





Adapted from ASTM 1076-15

Note:

Centrifuged ammoniated latex is diluted to 55% DRC with 1.6% ammonia solution

AFLatex is diluted to 55% DRC with distilled water

ALFA: MST between 800 and 1000 seconds



BETA: MST between 800 and 1200 seconds



AFLatex


VS

Ammoniated Natural Rubber





Protein and Phospholipids Branch Points





Odorless and non-toxic
Nitrosamine free



Superior mechanical
properties



No water treatment
facilities required



Eliminates health risks
to rubber industry workers

Lower allergenic
protein content



Extended latex shelf
life to over 6 years



In-house R&D and
patented
Latex
technologies



Working in
partnership with
multiple companies




AFLatex
technologies

**Environmentally
friendly natural
rubber & latex
eliminates toxic
additives**



SPE POLYMERS



Rodríguez Urbina, J.C., Osswald, T.A., Estela García, J.E., and Román, A.J., "Environmentally safe preservation and stabilization of natural rubber latex in an acidic environment," *SPE-Polymers*, 93–104, DOI: 10.1002/pls2.10089 (2023)

Román, A, Dibisa, O., Pardo, G., Rodríguez Urbina, J., Osswald, T., "Evaluation of an ammonia-free natural rubber latex adhesive," *SPE Polymers*, 5, 11-19, DOI: 10.1002/pls2.10103 (2024)

Osswald, T.A., Rodríguez, J.C., Adler, E.P., Estela Garcia, J.E., Pardo Morales, G. and Román, A.J., "A Novel Ammonia-Free Preservation and Stabilization Process for Natural Rubber Liquid Latex in an Acidic Environment," Latex Handbook, Chapter, TechnoBiz (2024)

Osswald, T.A., Rodríguez, J.C., Adler, E.P., Arroyave, H.A., J.E., Dibisa, O., Pardo Morales, G., and Román, A.J., "Applications of an Environmentally Friendly Natural Rubber Liquid Latex," Latex Handbook, Chapter, TechnoBiz (2024)

Dibisa, O., Arroyave, H., Rodríguez, J.C., Román, A.J., and Osswald, T.A., "Comparative Rheology and Microstructure Analysis of Natural Rubber Latex with Conventional and Eco-Friendly Preservatives," *Physics of Fluids*, 37 DOI: 10.1063/To be Published, (2025)

Dibisa, O., J.C., Román, A.J., Cabush, H., O'Brien, G., Kuang, X. and Osswald, T.A., "Ammonia-Free Natural Rubber Latex Photo-Resin for Sustainable 3D Printing of Highly Stretchable and Tough Elastomers," *SPE-Polymers*, 1-16, DOI: 10.1002/pls.270011 (2025)

ALSO PUBLICATIONS IN RESEARCH OUTLOOK, RUBBER NEWS, RUBBER WORLD
AND SLTCAUCHO

WILEY

 **spe** INSPIRING
PLASTICS
PROFESSIONALS



REINVENTEMOS EL CAUCHO
NATURAL PARA UN FUTURO MAS
SOSTENIBLE